

To Activate
Press/release any button.

Included in the package:


- VT 4.0 with CR2450 battery installed.
- CD (Manual, Oceanlog PC Interface program & drivers).

Included or optional:




- Transmitter with CR2 battery installed.
- Lens cover.
- Wrist strap extender.

Button Action

- S<2 - to access.
A<2 - to step up.
M<2 - to step back.
S<2 - to save.



Read & Understand the Operating Manual and Safety & Reference Manual





NORM (Surface)

at 5 ft (1.5 M) for 5 sec
at 2 ft (0.6 M) for 1 sec

NORM (Dive)


No Deco Main




Deep Stop Main



Safety Stop Main





COMPASS (Dive)



GAUG (Surface)

at 5 ft (1.5 M) for 5 sec
at 2 ft (0.6 M) for 1 sec

GAUG (Dive)



FREE (Surface)

at 5 ft (1.5 M) for 5 sec
at 2 ft (0.6 M) for 1 sec

FREE (Dive)

